SPEED FUSELAGE INSTRUCTION MANUAL 使用說明書

ALIGN

3D Unlimited Racing FOR TREX 450L



- 1 INTRODUCTION 前言
- 1 DESIGN FEATURES 設計特點
- 2 STANDARD EQUIPMENT 標準配備
- 2 EQUIPMENT REQUIRED FOR ASSEMBLY
- 3~9 ASSEMBLY SECTION

Please read this manual carefully before assembling. We recommend that you keep this manual for future reference regarding tuning and maintenance.

雖入遙控世界之前必須告訴您許多相關的知識與注意事項,以 確保您総夠在譽額的過程中較得心應手。在開始操作之前,請 那必詳閱本說明書,相信一定能夠給從專來相當大的幫助,也 請您公善疾營置本說明書,以作為日後參等。

INTRODUCTION

ALICE.

、前≥

Thank you for buying ALIGN Products. Please read the manual carefully before assembling the model, and follow all precautions and recommendations located within the manual. Be sure to retain the manual for future reference, routine maintenance, and tuning.

感謝您理構亞拓產品,請您詳細的閱讀完這本說明書之後再進行組裝以及操作這台直昇機,同時請您妥善的保存這本說明書、作為日後進行調整以及維修的參考。

IMPORTANT NOTES 重要聲明

We recommend that you obtain the assistance of an experienced pilot before attempting to fly our products for the first time. A local expert is the best way to properly assemble, setup, and fly your model for the first time. The requires a certain degree of skill to operate, and is a consumer item. Any damage or dissatisfaction as a result of accidents or modifications are not covered by any warrantee and cannot be returned for repair or replacement. Please contact our distributors for free technical consultation and parts at discounted rates when you experience problems during operation or maintenance. As Align Corporation Limited has no control over use, setup, final assembly, modification or misuse, no liability shall be assumed nor accepted for any resulting damage or injury. By the act of use, setup or assembly, the discretion of the control over use.

學型與風壓於無過時於超過五期時代之獨合。如照所從使用途。含血或不够有必需使規則。任何使用係必用底。 商品已已成本滿意。所無法於食因條件內更換新品或證實。如透有使用發作實情問題。 本公司金會分公司或代證廟 所提供技術訓練。特爾會件供服服務。對使用命的不確使用。超定、組收、6度、或數件不戶所造成的被賴或 各一本公司無法控制及負責。任何使用、設定、組裝、6度次、或操作不戶所造成的被賴。每外或傳書。使用者應承 達今階層作。



- Fly only in safe areas, away from other people. Do not operate R/C aircraft within the vicinity of homes or crowds of people. R/C aircraft are prone to accidents, failures, and crashes due to a variety of reasons incliuding, lack of maintenance, pilot error, and radio interference. Pilots are responsible for their actions and damage or injury occurring during the operation or as of a result of R/C aircraft models.
- Prior to every flight, carefully check rotorhead spindle shaft screws and tail blade grip screws, linkage balls and screws, ensure they are firmly secured.
- · 遙控模型飛機、直昇機屬高危險性商品,飛行詩務必逾離人群,人為組裝不當或機件損壞、電子控制設備不良 以及接供上的亦熟悉。都有可能導致飛行失控損傷等不可預期的息外,請飛行者務於注意飛行安全,並需了解 自身底忽形造成任何息外之責任。
- 每越飛行前須仔細檢查,主旋翼夾座橫輪螺絲、尾旋翼夾座螺絲,以及檢身各部位球頭、螺絲,確實上腳鎖緊 才能升空飛行。

DESIGN FEATURES 設計特點

ALICN

Utilizing wrap-around aerodynamic design, the brand new 4501. Speed Fuselage has an attention grabbing unique curve. Its tail section is wrapped with painted carbon fiber shell, resulting in superior visibility in mid-air, and further enhance the beauty of highly difficult maneuvers. The low aerodynamic drag enables high speed flights to be easily achievable. In addition, the ergonomic design simplifies installation, just a few simple steps with few screws to complete the install, easily outfling your helicopter with a beautiful body.

採用包覆式流線型設計的全新450L 關連機殼,外型突出亮製,尾部使用彩糖碳纖維尾殼包覆,擁有絕佳的空 中辨識度,能展現各個高難度飛行動作的內與第,低風阻設計更是能帶出高進飛行的快感。此外,人性化的 簡易安裝設計,只要幾個母聚聚,與關鍵整数安全等完成,複数為你的言葉排練上檢顯的新雄。

STANDARD EQUIPMENT

AL ICE

Competitive Speed Fuselage, suitable for T-REX 450L Dominator helicopter series. 競技協發,獲用於T-REX 450L Dominator 議時盲昇榜系列。

Before Assembling:

- Take inventory of all parts to ensure no missing pieces.
- 2. Some basic tools are needed to help with assembly.
- 组装前进借事语:
- 和被削华辆争项:
 1. 組裝之前請先確定內容物是否有缺失,仔細詳對後方可進行組裝。
- 2. 組裝過程裡需要一些簡單的工具協助組裝。



Competitive speed fuselage - Canopy 競速機設機頭罩

0 1

0

M2.5 Specialty washer M2.5特殊華司(φ2.5x ₀ 6x2mm) x 4 Socket button head screw 半蜀頭內六角螺絲 (M2.5x6mm) x2

450L Speed Fuselage Main Blade Holder 450L 部準期幹主際醫用定認

Socket button head screw 半題明內六角螺絲 (M2.5x10mm) x4 Socket screw 關頭內六角螺絲 (M2×20mm) x2

EQUIPMENT REQUIRED FOR ASSEMBLY

- -
- T-REX 450L Dominator
 無平衡關系经賣型網 T-REX 450L Dominator

六角螺絲肥子 1.5mm



Tool 自備工具
Hexagon Screw Driver

Ball Link Plier 拨豆餅 Blue ≝⊜ Ω


T43 Thread Lock T43 概略網

ALICN.

STEP1. 步驟1

Before assemble speed fuselage, please relocate Gpro/3GX Flybarless system to position 2 to prevent interfere when flying.

若T-REX 450L Dominator直屏機的 Gpro/3GX 是安裝於位置1,組裝競速機設前,請先將原位置1的 Gpro/3GX 移到位置2,被免干涉。




- Consult the following diagram for Gpro/3GX installation direction, with arrow pointing toward nose or tail of helicopter. Gpro/3GX needs to be mounted flat on gyro mounting platform, away from ubiration sources.
- Two pieces of foam mounting tape can be used if helicopter experiences vibration induced flight instability. However, if this still doesn't cure the problem, please check the helicopter mechanics and minimize mechanical vibrations, or reduce the headsneed.
- 1.Gpro/3GX擺放方向請参照圖示,方向指示薪頭指向機頭或機尾,水平擺放於陀螺藥固定座,並避開震動源。
- 2.機體震動會影響陀螺儀偵測,這成飛行不穩定,可於Gpro/3GX下方點附2片泡棉減震,若仍未改善,請 檢查機體排除震動或降低主旋翼轉速。

AL ICNI


STEP2. 步驟 2

- 1. Remove the M2.5x8mm socket button head screw from tail boom mount.
- 2. Remove the carbon fiber horizontal stabilizer, stabilizer mount, and tail boom brace set.
- 將鎮在尾管固定座上的半圓頭內六角螺絲M2.5x8mm拆下。
 將級繳水平關、水平關因定应與國民方線模拆下。



STEP3. 步驟 3

- Loosen the M2x18mm socket screw; and remove the vertical stabilizer and stabilizer mount.
- Remove the complete tail rotor assembly.
- 1. 這數間關頭內六角螺絲M2x18mm螺絲,將垂直鑿線垂直固定座拆下。
- 2. 將尾旋鑿網際網振下。




ASSEMBLY SECTION 組裝步驟

ALICN.

STEP4. 步驟4

- Temporarily mount the carbon fiber vertical stabilizer and vertical stabilizer mount on the speed fuselage's tail boom cover by threading it with M2x20mm Socket screw.
- Slide the speed fuselage's tail boom cover onto the carbon fiber tail boom from the rear; secure with socket screw.
- 先將碳繼垂直翼、垂直固定座用圓頭內六角螺絲M2x20mm穿邊競速機殼尾管固定。
- 將競速機殼尾管由後方穿入套在碳纖尾管上,鎖上圓頭內六角螺絲。



ALICN

STEP5. 步驟5

Re-install the tail rotor assembly into the tail boom; tighten the Socket screw on vertical stabilizer.

將尾旋翼組裝回尾管,再將固定在垂直翼上的圓頭內六角螺絲鎖緊。



(Tail rotor assembly) (尾旋聲組)

Apply a little amount of T43 thread lock when fixing a metal part. 螺絲鎖附於金鬈件請使用適量T43 (螺絲瓣)

⚠ CAUTION 淮 東


When fixing M2x20mm Socket screw, apply some T43 thread lock and tighten with suitable force. Over-tighten will cause crack and damage the fuselage. askindx2x0mm國的六百億年齡,使用國軍143以國第十四日中,國軍第,以際國際的國際經濟。



STEP6. 步驟6

Ensure the correct installation of speed fuselage tail boom cover, then install the speed fuselage canopy from front of the helicopter. Mount the canopy over the canopy mounting bolt.

確認競速星管網裝無路,再將競速機發機頭壓由機身前而能入,扣入機頭罩因定柱。




ASSEMBLY SECTION 組裝步驟

VI ICN

COMPLETE ILLUSTRATION 組裝完成圖

Before flying, please carefully check every part again to make sure all parts are firmly secured without any interference.

請再詳細檢查名部位是否確實調緊與固定,並確定無干涉情形後才可以飛行。



9

www.align.con

www.align.co

www.align.com.tw www.ali

www.align.com.tw







